```
#include <SimpleDHT.h>
#include <LiquidCrystal.h>
char d;
// for DHT11,
// VCC: 5V or 3V
    GND: GND
    DATA: 2
int pinDHT11 = 8;
SimpleDHT11 dht11(pinDHT11);
LiquidCrystal lcd(2,3,4,5,6,7);
void setup() {
 Serial.begin(9600);
 lcd.begin(16, 2);
}
void loop() {
if(Serial.available())
{
 d=Serial.read();
}
if (d=='a')
{
// read without samples.
 byte temperature = 0;
 byte humidity = 0;
 int err = SimpleDHTErrSuccess;
```

```
if ((err = dht11.read(&temperature, &humidity, NULL)) != SimpleDHTErrSuccess) {
    return;
}

//Icd.setCursor(0,0);

//Icd.print("Temp is ");

//Icd.print((int)temperature); Icd.print(" *C, ");

//Icd.setCursor(0,1);

//Icd.print("Humidity:");

//Icd.print((float)humidity);

Serial.println(temperature);

Serial.println(humidity);

// DHT11 sampling rate is 1HZ.

delay(1500);
}
```